

MONDAY NIGHT CLEAN BACKSIDE OF MACHINE

- CLEAN BEHIND 1ST AND 2ND DRYER SECTIONS. {I.E. VACUUM BRUSH OR WASH}.
- CLEAN BEHIND SIZEPRESS. SPOONER DRYER AND REELEND.
- REMOVE ALL DEBRIS { I.E. LOOSE PAPER. NUTS/ BOLTS.PLASTIC. WOOD}
- REPORT ON DEBRIS LEFT BEHIND BY OTHER DEPARTMENTS.

