

TUESDAY DAY

WASH AND CLEAN BEHIND FORMER

- WASHDOWN SOME PIPEWORK AND FRAMEWORK AS BEST AS POSSIBLE.
- CLEANOUT LOOSE BROKE AND DEBRIS FROM UNDER TAD1 DUCTING.
- WASH FLOOR AREA AROUND CLEANERS AND BEHIND THE FORMER AND TRANSFER SECTIONS.
- REMOVE ALL DEBRIS.
- REPORT ON ANY DEBRIS LEFT BEHIND BY OTHER DEPARTMENTS.

